

# GOKU Versatile F411VTX

Definition diagram

Note:  
 SET SERIAL UART  
 resource SERIAL\_TX 11 B00  
 resource SERIAL\_RX 11 B04

